



**Gamers  
Outreach®**  
Helping Others Level Up

## GO Kart Assembly Manual

hello  
there!

We're Gamers Outreach,  
a nonprofit on a mission  
to make **PLAY** accessible  
inside hospitals.



For questions or maintenance support, please reach out to us via email at [contact@gamersoutreach.org](mailto:contact@gamersoutreach.org).  
You can also find us online, [www.GamersOutreach.org](http://www.GamersOutreach.org) or across social media platforms, [@GamersOutreach](https://www.instagram.com/GamersOutreach).  
To view these instructions online, visit: <https://gamersoutreach.org/go-kart-information>

ABOUT US

Congratulations on receiving your new GO Kart unit! GO Karts (Gamers Outreach Karts) are portable video game kiosks built for hospitals. Each unit can be equipped with a video game console or PC (depending on your preference!) to provide patients with easy access to entertainment.

DONOR PLACARD

If your GO Kart was provided by a donor, you should've also received a donor placard in the mail. This placard is intended to be placed horizontally along the top of the GO Kart, just behind the controller lid.

We kindly ask you to ensure the placard remains atop the kart. Donors are an important part of making the GO Kart program possible, and the placards are intended to recognize their support.


If you have any questions or need a new placard, please feel free to contact us!

SETUP INSTRUCTIONS

**PARTS LIST/**


Note: velcro ties can be used to secure your console in place during movement.

1




Hand Screw x 4

2




Hand Screw x 2




Scan the QR code to watch a setup video for your new GO Kart!

A




Rear Legs x 1

B




Front Legs x 1

C




Lift Component x 1

D




Feet Cover x 1

E




Tray Module x 1

F




Key x 1

G




Monitor Mount x 1

H




Monitor Plate x 1

I



Metal Plate x 2  
(for securing PS & Xbox)

J



Velcro Ties x 1

STEP/

Attach the rear legs to the lift component using two of the included hand screws.

\*the guide pins will help you ensure the rear legs are being affixed to the correct side.

STEP/

Flip over the lift component and attach the front legs using the remaining two hand screws.

\*the guide pins will help you ensure the front legs are being affixed to the correct side.

STEP/

Stand up the module. Slide the feet cover over the lift component so that it sits atop the legs.

STEP/

Slide the tray module on to the top of the lift component.

STEP/

Find the key in the controller bin. Unlock the tray lid to open the tray cover.

\*the lock is located on the back of the tray next to the TV mount cavity.

STEP/


Slide the monitor mount into the mount cavity. Tighten the monitor mount using the two hand screws. Then close the lid.

STEP/

Attach the monitor plate to your GO Kart's TV screen. Slide the monitor plate into the monitor mount, and use the hand screw to secure the TV.

# finished product

That's it! Your GO Kart is ready for action!



## ECO-FRIENDLY DESIGN

We are committed to doing our part to build products with sustainable materials, including metals and reinforced plastic that provide durability and performance. We contribute to the environment in the following ways:

### 1. Waste and Resource Reduction

Our design emphasizes the use of recyclable materials to reduce reliance on finite resources and minimize waste generation.

### 2. Extended Product Lifespan

By selecting high-quality materials, we've made our product more durable, extending its service life and reducing the need for replacement or disposal.

### 3. Promoting Material Circularity

We encourage customers to recycle materials from the product, ensuring these resources are reused, reducing the demand for new raw materials.




### Recommended Use

1. We suggest using a TV/monitor no larger than 24 inches/8 kg (17.6 lbs). Large monitors that extend past the handle bars may get damaged bumping into objects.
2. The GO Kart is not a piece of playground equipment! Please avoid hanging on the handle bars or sitting on the surface of the GO Kart. Placing excessive weight on one side of the GO Kart may cause damage or tip the unit.
3. Your GO Kart is designed to accommodate a variety of video game equipment. Please do not load the surface tray and storage bin with more than 20 kg (44 lbs) of weighted objects.
4. Always be sure to wrap the extension cable when the GO Kart is not in use to prevent tripping hazards.

## ADJUSTABLE HEIGHT


Lock the wheels of the GO Kart. Step on the paddle to raise/lower the height of the tray by pulling up or pushing down on the handle bars of the unit.




## GAMING CONSOLE INSTALLATION

Place the metal plates and secure them to the console tray. Insert your desired gaming console and connect all corresponding cables. Cables can be routed through the monitor mount for easy management. The plastic covering on the monitor mount can be removed or re-affixed by hand. Now you're ready to PLAY!


### For PS



### For Nintendo Switch




### For Xbox



### Before inserting your Nintendo Switch

Unscrew and remove the front board (1). Replace it with the Switch front board (2), and secure the board by tightening the screws.



## MATERIALS LIST

1. **Iron:** Primarily used for the product's structural framework, providing robust support and durability.
2. **Aluminum:** Used to enhance the product's lightweight nature while offering excellent corrosion resistance, employed in the casing and support components.
3. **PP with Glass Fiber Plastic Parts:** These plastic components are used to provide insulation properties and structural support. Glass fiber-reinforced PP material boasts excellent strength and durability.



## RECYCLING INSTRUCTIONS

To ensure your product makes a positive environmental contribution, consider the following recycling guidelines:

1. **Disassemble Components:** Before disposal, it's advisable to disassemble the product into its primary material parts, such as iron, aluminum, and plastic parts. This facilitates easier recycling and processing of these materials.
2. **Metal Recycling:** Iron and aluminum are highly recyclable metals. You can deliver these parts to your local metal recycling center to ensure they undergo proper processing and reuse.
3. **Plastic Recycling:** The PP with glass fiber plastic parts can also be recycled. Please take these parts to a local plastic recycling facility to ensure they are properly reprocessed.
4. **Environmentally Responsible Disposal:** If material disassembly or recycling is not feasible, make sure to dispose of the entire product at your local waste disposal facility for proper handling.

## CLEANING INSTRUCTIONS

Exterior surfaces of the GO Kart, especially common touch points, should be disinfected on a regular basis. The vast majority of disinfectants are safe for use on GO Karts.

For peripheral cleaning (i.e. Xbox, TV, or controllers), please follow the manufacturer's directions when using disinfectants as part of normal infection control procedures.

Prior to disinfecting cart surfaces, loose debris and residues should be removed. Clean surfaces using a damp cloth or towel with warm water. If a liquid solution is used for disinfection (as opposed to saturated wipes), we recommend applying the solution to the applicator cloth or towel. To prevent spillage, it is not recommended to pour liquid solution directly to any cart surface.

## WARRANTY INFORMATION

GO Karts come with our standard two year warranty, which can be upgraded to a Super Warranty for a monthly subscription. For information regarding our warranty policies, or to subscribe to a Super Warranty, please visit <https://gamersoutreach.org/go-kart-information>

## MEETS UL AND CE STANDARDS

This device is built to meet UL and CE standards.



## WARNINGS

A) WARNING/CAUTION - Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child.

B) WARNING/CAUTION - Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto a child.